

L171

Quick Start Guide | Schnellanleitung | Guide de démarrage rapide
Guida Rapida all'uso | Guía de inicio rápido




 **Avantree**[®]

Model No.: ADHF-L171


Product Overview

Produktübersicht | Vue d'ensemble du produit | Panorámica
Prodotto | Descripción general del producto




Contact Us

Kontaktieren Sie uns | Contactez-nous | Contattaci | Contáctenos

 **Support Tickets** avantree.com/submit-a-ticket

 **Support Email** support@avantree.com

 **US/CA** +1 800 232 2078 (9am-6pm, PST, Mon-Fri)

UK +44 20 8068 2023 (9am-6pm, GMT, Mon-Sat)

DE +49 32221097297 (11am-9pm, CET, Mon-Sat)


FR +33 176340312 (11am-9pm, CET, Mon-Sat)

IT +39 06 9480 3330 (9am-6pm, CET, Mon-Sat)

ES +34 931786261 (9am-6pm, CET, Mon - Sat)

AU +61 2 8310 9897 (11am-7pm, AEST, Mon-Fri)

 **FAQ** avantree.com/support/l171

 **Product Registration** avantree.com/product-registration

EC REP

Name: Gizmex GmbH
Company Address: Sternstr. 67, 40479 Dusseldorf, Germany.



Model No:ADHF-L171
Dispose of the packaging and this product in accordance with the latest provisions.
Z-PKQG-L171-V0

Online Support

Soporte en línea | Support en ligne | Supporto Online |
Soporte en línea

Troubleshooting&FAQ

EN 1. One side has not sound. What Should I Do?
2. The earbuds buttons do not work. What should I do?

DE 1. Eine Seite hat keinen Ton. Was soll ich machen?
2. Die Tasten der Kopfhörer funktionieren nicht. Was soll ich machen?

FR 1. Un côté n'a pas de son. Que devrais-je faire?
2. Les boutons des écouteurs ne fonctionnent pas. Que devrais-je faire?

IT 1. Un lato non ha suono. Cosa dovrei fare?
2. I pulsanti degli auricolari non funzionano. Cosa dovrei fare?

ES 1. Un lado no tiene sonido. ¿Qué tengo que hacer?
2. Los botones de los auriculares no funcionan. ¿Qué tengo que hacer?

Need further assistance?
Visit avantree.com/support/l171

