# AS70P


Quick Start Guide I Schnellanleitung I Guide de démarrage rapide I Guida Rapida all'uso I Guía de inicio rápido





#### **Product Overview & Box Contents**

Produktübersicht und Verpackungsinhalt | Présentation du produit et contenu de la boîte | Panoramica del Prodotto e Contenuto della Confezione | Descripción General del Producto y Contenido del Paquete



# Contact Us Kontaktieren Sie uns | Contactez-nous | Contattaci | Contáctenos

| کنے | Supp          | ort Tickets                   | avantree             | .com/submit-a-ticket |         |  |  |
|-----|---------------|-------------------------------|----------------------|----------------------|---------|--|--|
|     | Support Email |                               | support@avantree.com |                      |         |  |  |
| 6   | Supp          | Support Numbers               |                      |                      |         |  |  |
|     | US            | +1 800 232                    | 2078                 | 9am-6pm PST          | Mon-Fri |  |  |
|     | CA            | +1 800 232                    | 2078                 | 9am-6pm PST          | Mon-Fri |  |  |
|     | UK            | +44 208 06                    | 8 2023               | 9am-6pm GMT          | Mon-Sat |  |  |
|     | DE            | +49 322 21                    | 09 7297              | 11am-9pm CET         | Mon-Sat |  |  |
|     | FR            | +33 17 634                    | 0312                 | 11am-9pm CET         | Mon-Sat |  |  |
|     | IT            | +39 069 48                    | 03 330               | 9am-6pm CET          | Mon-Sat |  |  |
|     | ES            | +34 93 178                    | 6 261                | 9am-6pm CET          | Mon-Sat |  |  |
|     | AU            | +61 2 8310                    | 9897                 | 11am-7pm AEST        | Mon-Fri |  |  |
| ?   | FAQ           | Q avantree.com/support/as70-p |                      |                      |         |  |  |

Manufacturer: Avantronics Limited Luohu District, Shenzhen 518000 China + 86 755 8228 5022 support@avantree.com

US Importer: Avantree Corporation San Jose, California 95119 USA +1800 232 2078 support@avantree.com

UK Importer: Avantree Limited Watford, WD180 0HQ UK +44 20 8068 2023 support@avantree.com







#### Item No.: BTHS-AS7 pose of the packaging and this product in accordance with the latest provision

#### **Button Functions**

| Button | Functions   |  |  |  |  |
|--------|---|--|--|--|--|
|        | Slide to ●/○ to turn on / off                               |  |  |  |  |
|        | Slide to * and hold for 2 seconds to enter pairing mode     |  |  |  |  |
|        | Slide to ≯ once to reconnect the latest device              |  |  |  |  |
|        | Press once to play / pause                                  |  |  |  |  |
| N.II   | Press once to accept / end call                             |  |  |  |  |
| ▶II    | Press & hold for 2 seconds to reject call                   |  |  |  |  |
|        | Press twice to redial last number                           |  |  |  |  |
|        | Press once for volume up / down                             |  |  |  |  |
| +      | Press and hold for 2 seconds for next / previous track      |  |  |  |  |
|        | Press and hold both for 5 seconds to clear pairing history  |  |  |  |  |
|        | Switch between balance / bass mode                          |  |  |  |  |
| MODE   | Press once to unmute / mute microphone                      |  |  |  |  |
|        | Press and hold MODE and + / - to turn voice prompt ON / OFF |  |  |  |  |

EN

#### **LED Indicator**

| Indicator  | Status                      |
|--|-----------------------------|
| Alternate red & blue flashes                         | Pairing                     |
| Solid blue   | Connected via classic audio |
| Solid white  | Connected via LE audio      |
| Solid blue & red simultaneously (pink) for 2 seconds | Clearing pairing history    |
| Red flashes every 20 seconds                         | Low battery                 |
| Solid red  | Charging                    |

#### **Connect to a Bluetooth device**

**STEP 2** On your device - Activate Bluetooth, search & select "Avantree AS70P" to connect. If you're using a Bluetooth transmitter, enter it into PAIRING Mode.





STEP 3 Keep the AS70P & your device close together and wait for 5-10s until they connect. Once connected, the LED indicator will turn a solid color. If you have headphones plugged in, you'll hear "connected".

### **Reconnect to a Bluetooth device**

Once powered on, the AS70P should automatically reconnect to the last connected device within 5-10 seconds. If not, please select "Avantree AS70P" from your device's Bluetooth menu to connect manually. (If using a Bluetooth transmitter, please refer to its user manual.).

### Charging

When the LED indicator flashes Red, you should charge the device. Using the provided type C cable, plug the AS70P into either a wall outlet - 5V/500mA-1A rated USB adapter (any phone charger should work) or a PC USB port. The LED indicator will turn solid red while charging and off when completed. It normally takes around 2 hours to fully charge.

# **FAQ**

Below are some of the most common questions people have during setup.

How to upgrade the software?

You can do the device firmware upgrade (DFU) yourself. Pls follow the instructions from our support site: avantree.com/as70p/how-to-do-dfu

#### During a call, how to have myself being heard more clearly?

It's best to clip the AS70P to your collar; point the microphone hole upward and close to your mouth.

#### How to switch to LE Audio on my phone?

.....

For answers and a full FAQ, please visit avantree.com/support/as70p for assistance.