Avantree Roadtrip


Wireless Car Speakerphone

User Manual

Content

Product overview & Box contents	2
Basic operations	3
Connect speakerphone to smartphone	3
Connect to 1st smartphone (first time use)	3
Connect to 2 nd smartphone	4
Reconnecting	4
Stream audio from car stereo (FM transmitter connection)	4
How to set FM frequency?	4
Install speakerphone to sun-visor	4
Enable/Disable "Auto power on/off" function	5
Charging	5
Clear pairing history/factory reset	5
LED indicators & Voice prompts	5

Product overview & Box contents





USB car charger USB Kfz-Ladegerät Chargeur USB allume-cigare Caricabatterie USB da auto Cargador de coche USB



USB cable USB Kabel Câble USB Cavo USB Cable USB

Basic operations

General function >

Power on/off	Slide the OFF/ON/FM Switch to "ON" or "OFF".		
Enter Pairing Mode	Hold for 2 seconds until Bluetooth status LED flashes BLUE and RED alternately		
Manually reconnect	Short press short press once		
Voice control	Short press once to enable/disenable the voice control on your phone. (This is phone feature -make sure your phone support Siri, Google assistant, etc.)		
Turn on FM transmitter	Slide the OFF/ON/FM switch to "FM" position		
FM frequency select	When in FM transmitter mode, rotate 📞 to select FM frequency		

Music control >

Adjust volume	Rotate to adjust volume (Not available when in FM transmitter mode, p use the volume control on your car radio instead)	
Play/Pause	Short press C	
Next/Previous track	Double/Triple click ©	

Call control >

Answer/End a call	Short press C
Reject a call	Hold of for 2s when receiving an incoming call
Last number redial	Double press C
Mic mute on/off	Short press once to toggle mic mute on/off during a call. Once mic mute on, the status LED will keep RED.

Connect speakerphone to smartphone

Connect to 1st smartphone (first time use)

- 1. Slide OFF/ON/FM switch to "ON" position to turn on speakerphone. It will automatically go into **PAIRING MODE** status LED flashes **BLUE** and **RED** alternately.
- 2. On your device Turn on Bluetooth, search and select "Avantree Roadtrip" to connect.
- 3. Once connected, you will hear "Connected" prompt from speakerphone.



Connect to 2nd smartphone

- 1. Put the speakerphone into PAIRING MODE again Hold for 2 seconds until the status LED flashes BLUE and RED alternately. Speakerphone will disconnect with the 1st smartphone.
- 2. Repeat previous step to connect to the 2nd smartphone.
- 3. Tap "Avantree Roadtrip" on the 1st smartphone to reconnect them. And now, the speakerphone should be connected to both smartphones.

Reconnecting

Once the speakerphone is switched "ON", it will automatically reconnect to last connected phone. For other paired phones, please tap "Avantree Roadtrip" on your phone to reconnect.

Stream audio from car stereo (FM transmitter connection)

- 1. Slide OFF/ON/FM switch to "FM" position.
- 2. Choose a **vacant FM frequency channel from your car radio**. Most vacant channels contain constant static/buzz sound. These channels are commonly found below 90.0MHz and above 107.0MHz.
- 3. Rotate to set the frequency of speakerphone to the same as your car radio. Now, you can stream your phone's audio from car stereo.




How to set FM frequency?

In FM transmitter mode, there are two ways:

- Rotate the knob switch to change the FM frequency steps to **0.1 MHz per step**.
- Press and hold the knob switch until the FM display flashes. And then, rotate the knob switch to change the FM frequency steps to 1 MHz per step.

Install speakerphone to sun-visor

Clip the Avantree Roadtrip to the sun visor above the driver's seat.



Enable/Disable "Auto power on/off" function


When the OFF/ON/FM switch is set to "ON" or "FM", the "Auto Power On" function is activated.

- Auto power off When you leave your car and your phone disconnects from the speakerphone about 10 minutes later, it will auto turn off.
- Auto power on Once you open your car door, the speakerphone will auto turn on.

The "Auto Power On/Off" function can be disabled by sliding the OFF/ON/FM switch to "OFF".

Charging

When you hear a "Low battery" prompt, or see the RED LED, you should charge the device. It will take about 1.5 ~2 hours to fully charge.



Clear pairing history/factory reset

Conducting a factory reset on the speakerphone will clear all past pairing data and restore the default settings for the product. You may want to reset your Roadtrip if you have trouble pairing them with your devices.

- 1. Put the speakerphone into PAIRING MODE again Hold (1838) for 2 seconds until the status LED flashes BLUE and RED alternately.
- 2. Press twice to RESET the Roadtrip. The LED will briefly flash PINK before return to pairing mode, indicating that it has reset.

LED indicators & Voice prompts

LED INDICATOR STATUS	SPEAKERPHONE STATUS	VOICE PROMPTS
Blue led on 1 second	Power on	"Power on"
The red and blue led flash alternate	Pairing in progress	"Pairing"
/	Successful connection	"Connected"
Blue led flash once every 5 seconds	Connected	/
/	Failed connection or disconnected	"Disconnected"
Blue led steady on	Standby (Disconnected)	/

Red led steady on	Microphone muted during a call	/
Red led flash once every 5 seconds Red led steady on	Low battery (connected)) Low battery (Disconnected standby)	"Battery low"
Red led on 1 second and then off	Power off	"Power off"
Red led steady on	Charging in progress	
Red led off	Charging completed	