# SoundJet R1

**User Manual** 



**Avantree**<sup>®</sup>

Model No.: BTTC-219


## **Table of Contents**

PRODUCT INTRODUCTION		
Product Overview		
BUTTON FUNCTIONS		
LED Indicators		
CONNECTING TO YOUR HEADPHONES	2	
ADDING A SECOND PAIR OF HEADPHONES		
RECONNECTING YOUR HEADPHONES		
CHARGING		
SPECIFICATIONS	4	
CONTACT US	4	

User Manual SOUNDJET R1

### **Product Introduction**

### **Product Overview**



### **Button Functions**

No.	Button	Functions
Multifunctional 1 Button (MFB)		From off, press & hold for 2 seconds to turn the SoundJet R1 on
		From on, press & hold for 2 seconds to turn the SoundJet R1
	into pairing mode	
	Button (MFB)	From on, press & hold for 5 seconds to turn the SoundJet R1 off
		Press once to manually initiate reconnection to last-paired
		device
2		Press once or hold to adjust volume
	Volume + & -	Press & hold both for 6 seconds to clear pairing history
		(Reset)


### **LED Indicators**


	Indicator	Status	
	Alternate red & blue flashes	Pairing	
	Solid blue	Connected	
Hoadphonoo	Divide fleebook event accord	Reconnecting to last-used	
Headphones LED	Blue flashes every second	device	
	Blue flashes every 5 seconds	Standby	
	Solid blue & red simultaneously for	Clearing pairing history	
	3 seconds	Clearing paining history	
Battery &	Solid red	Charging	
Charging	Turns off	Fully charged	
led	Red flashes	Low battery	

## Connecting to Your Headphones

### STEP 1

Turn on the SoundJet R1 by press the MFB button 2 seconds. For first time use, the SoundJet R1 will enter PAIRING mode automatically. For subsequent use, put your SoundJet R1 into PAIRING mode by pressing MFB until the LED flashes blue and red alternately.





#### STEP 2

Put your Bluetooth headphones into PAIRING mode.

\* NOTE: Most cases where your device & the transmitter fail to connect happen because the device is not properly placed into PAIRING mode. Double check that your device is successfully in PAIRING mode (typically indicated by an LED indicator's alternate red & blue flashes). For more details, please refer to your device's online user

User Manual SOUNDJET R1

manual. Airpods in particular will always prioritize Apple devices for automatic pairing, so you'll need to turn your iPhone's Bluetooth OFF when pairing your Airpods with the SoundJet R1.

#### STEP 3

Keep the SoundJet R1 & your device close together and wait for 5-10s until they connect. Once connected, the indicator will turn solid blue.

Now Plug the SoundJet R1 into an in-flight entertainment system (Please contact us if you need a dual 3.5mm adapter.) or any other audio source with an AUX 3.5mm audio connector, you can enjoy the audio.



## Adding a Second Pair of Headphones

You can connect and simultaneously listen through two pairs of headphones if desired.

#### STEP 1

Once your first device is successfully connected, put your SoundJet R1 into PAIRING mode once again by pressing & holding the MFB until another headphone LED flashes blue and red alternately.

#### STEP 2

Put your second pair of Bluetooth headphones into PAIRING mode. Please refer to your headphones' user manual for more details if necessary.

#### STEP 3

Keep the Soundjet R1 & your second device close together and wait for 5-10s until they connect. Once connected, both headphone indicators will turn solid blue.

\*NOTE: The dual headphones support function works with most headphones but not all. Certain true wireless earbuds in particular do not work well with Bluetooth transmitters' dual headphones mode. If you're not getting audio while dual linked, try turning the affected headphones off and then on again.

In some cases, dual pairing with Airpods may trigger their audio MUTE function. If this h appens, put them back in their charging case (with the lid open) for 2 seconds, then take them out again to return them to normal. This may help to solve the problem.

### Reconnecting Your Headphones

You typically do NOT need to re-pair your Bluetooth headphones with the SoundJet R1 every time. Once successfully paired, they should automatically reconnect when both devices are turned on (this may take a few seconds).

If your device does not automatically reconnect after 5-10 seconds, you can manually initiate reconnection by pressing the SoundJet R1's MFB once and waiting for 5-10 seconds. If this still doesn't work, try initiating reconnection on your audio device as well (typically done by pressing the main Bluetooth PLAY button on your headphones once).

If they still don't connect, you may need to re-pair your device.


\*NOTE: If you paired your headphones with a different Bluetooth device.

\*NOTE: If you paired your headphones with a different Bluetooth device, turn Bluetooth OFF on said device(s).

User Manual SOUNDJET R1

## Charging

It is in low battery if the Battery & charging LED flashing red. Plug the provided USB C charging cable into the charging port, then connect the other end to a 5V/500mA-2A rated USB adapter (your phone charger or similar should work) or PC USB port.



A solid red light on the transmitter indicates that charging is in progress; the LED will turn off to indicate a full charge.

## **Specifications**

Bluetooth version	v5.3
Supported profiles	A2DP; AVRCP
Audio codecs	aptX adaptive; aptX Low Latency, aptX, SBC
Input voltage / current	DC5.0V / 500Ma-2A
Operating range	Up to 33ft / 10m
Product dimensions	125mmx24mmx12mm
Net weight	15g

### Contact Us

$\Xi$	Support Tickets	avantree.com/submit-a-ticket		
	Support Email	support@avantree.com		
وي	Support Numbers			
	US	+1 800 232 2078	9am-6pm PST	Mon-Fri
	CA	+1 800 232 2078	9am-6pm PST	Mon-Fri
	UK	+44 208 068 2023	9am-6pm GMT	Mon-Sat
	DE	+49 322 2109 7297	11am-9pm CET	Mon-Sat
	FR	+33 17 634 0312	11am-9pm CET	Mon-Sat
	IT	+39 069 4803 330	9am-6pm CET	Mon-Sat
	ES	+34 93 1786 261	9am-6pm CET	Mon-Sat
	AU	+61 2 8310 9897	11am-7pm AEST	Mon-Sat
?	FAQ	avantree.com/support/soundjet-r1		

#### Manufacturer:

Avantronics Limited

Luohu District, Shenzhen 518000 China + 86 755 8228 5022

support@avantronics.com

#### **Battery Manufacture:**

CHONGQING VDL ELECTRONICS CO., LTD. Building 1-4, Puli Industrial New Area, Zhaojia Street, Kaizhou District, Chongqing, China 86 (0) 23-52862502

customers@gdvdl.com

#### US Importer:

Avantree Corporation San Jose, California 95119 USA +1 800 232 2078

support@avantree.com

### **REP**

Avantree Europe Z O.O. UI. żOłNierzy I Dywizji Wojska Polskiego 78A/2

84-230 Rumia Pomorskie, Poland +48 22 307 25 37

support-eu@avantree.com







Model No.: BTTC-219 FCC ID: WJ5-BTTC-219 IC: 8475A-318 Made in China

### UK Importer:

Avantree Limited Watford, WD180 0HQ UK +44 20 8068 2023